

ABSTRACT

The present invention provides a compact tablet storage and take-out apparatus capable of quickly discharging and filing tablets. The tablet storage and take-out apparatus includes: a cylindrical drum; drum driving means; a plurality of tablet cassette mounting bases (341) which are fitted to an outer surface of the drum; tablet cassettes which are detachably mounted on the tablet cassette mounting bases; and a guide passage which guides inside the drum tablets discharged from the tablet cassettes. Moreover, the apparatus includes: a transfer robot which is provided inside the drum so as to be liftable and also rotatable, and which transfers the vial held by arms between a delivery position located outside an opening formed in an upper end or a lower end of the drum and a tablet filling position where the tablets discharged through the guide passage are filled. The position of at least one of the drum and the transfer robot is controlled so that an opening of the vial held by the transfer robot agrees with an outlet of the guide passage.

FIG.6

1. Operation display panel
2. Vial supply part
Rotation driving device
Bottle detection sensor
Position detection sensor
3. Labeling part
4. Tablet supply part (Drum)
5. Cassette identification sensor
Tablet detection sensor
Rotation driving device
6. Tablet supply part (motor base)
7. Bottle detection sensor
Inversion driving device
Rotation driving device
Discharge driving device
8. Cap supply part
9. Parallel moving device
Push-up driving device
Rotation driving device
Position detection sensor
Cover detection sensor
10. Capping part
11. Bottle detection sensor
12. Storage part

13. Host computer
14. PC (Device control application)
15. Device controller
16. Photographing part
17. Digital camera
18. First transfer robot
19. Position detection sensor
Elevation driving device
Parallel moving device
Arm driving device
20. Second transfer robot
21. Elevation driving device
Arm driving device
Oscillation driving device
Extension-Contraction driving device
Rotational driving device
Position detection sensor
Bottle detection sensor
22. Third transfer robot
23. Fourth transfer robot

FIG.24

1. Second robot arm
2. Start
3. Move to delivery position

- Vial detected?
- Extend arm boom
- Located at holding position?
- Stop extension of arm boom
- Hold vial
- Contract arm boom
- Located at origin
- Take-out coordinates received?
- Lifting and rotational movement
- Arm base at tilt position
- Take-out coordinates reached?
- Extend arm boom
- Take-out position reached?
- Standby for filling period
- 4. Remaining tablets dropping operation
- 5. Oscillating operation
- 6. Tablets tend to remain?
- 7. Filled amount 65% or more?
- 8. Arm base at horizontal position
- Move to delivery position
- Delivered?

FIG.25

- 1. Mutual control
- 2. Start

Take-out coordinates received
 Detect current drum coordinates
 Detect current arm rotational coordinates of second transfer robot
 Determine rotation directions within rotation limits
 Estimate coordinates of intersection of drum coordinates and arm
 rotational coordinates
 Rotate drum
 Rotate second transfer robot
 Coordinates of intersection reached?
 Stop both rotations

FIG.26

1. Drum control
2. Take-out coordinates reached?
Stop drum rotation

FIG.27

1. Robot arm control
2. Stop rotation of second transfer robot

FIG.32

1. Double drum
2. To flow of any one of
Robot arm control
Drum control

Mutual control

3. Outer drum?

Detect current coordinates of outer drum

Detect current coordinates of inner drum

Determine rotation directions within rotation limits

Estimate intersection coordinates of outer drum and inner drum

Rotate outer and inner drums

Intersection coordinates reached?

Stop outer and inner drums

FIG.33

1. Auxiliary transfer robot

2. Outer drum take-out coordinates received.

Standby at delivery position

Vial arrived?

Extend arm boom

Hold vial

Contract arm boom and swivel

Elevating base

FIG.36

1. Third robot arm

2. Start

Move to first delivery position

Vial empty?

Vial detected?
Hold vial
Move to second delivery position
Transmit photographing permission signal
Photographing completion signal received?
Move to third delivery position
Delivery to capping part
Release arm
Standby at current position
Cap fitting completion signal?
Hold vial
Move to fourth delivery position
Delivered?

FIG.37

1. Photographing initialization
2. Start
Main body turned ON?
Turn On PC
Activate device control application
Transmit initialization signal
Obtain initial origin of each device
Turn ON camera
Make initial zoom setting
3. Select image size

Define image quality
Set flash
Color balance
Receive initialization completion signal

FIG.38

1. Photographing control
2. Start
Photographing permission signal received?
Auto-focus detection
Focus control
Photographing signal
Access photographing image file
Transfer and temporality save data
Monitor display
Manual check ON?
3. Clear temporary data
4. Image saving permission operated?
Transmit photographing end signal

FIG.39

1. Photographing part 400
2. Device controller 802
3. At initial process
4. Activate vial application

5. Transmit initialization data
6. Initialize camera
7. Turned power ON or designate initialization
8. Initialize each device and wait for packing data
9. At packing process
10. Transmit packing designation
11. Designate photographing with camera
12. Save image
13. Transmit photographing completion
14. Photographing with camera
15. Transmit camera image
16. Packing processing
17. Photographing position
18. To the next process
19. At ending processing
20. End vial application
21. Camera closing processing
22. Turn power OFF

FIG.40

1. Photo display upon packing completion
2. COMPLETE screen
3. Notify packing completion
4. Notification of pickup
5. Pickup confirmation screen

6. Enlarged photo screen
7. Designate photo enlargement
8. Complete packing
9. Bottle to dispensing window
10. Blink corresponding 7SEG
11. Confirm pickup operation
12. Read prescription bar code
13. Pickup bottle
14. Confirm prescription details
15. Photo display after packing completion confirmation
16. PHOTO list screen
17. Photo screen
18. PHOTO list screen
Designate prescription
19. Read in bar code of dispensed bottle label.

FIG.42

1. Pyrazolone tablets with external tablet supply part
2. Start
Prescription data received.
External tablet supply part designated?
Tablet cassette detected?
Discharge tablets
Select vial size
Create print data

Transmit data
 Transfer vial by first transfer robot
 Printing and labeling by labeling part
 Transfer vial by first transfer robot
 Transfer vial by third transfer robot
 Transfer vial by fourth transfer robot
 Vial taken out?
 Tablets filled?
 Photographing to be omitted?
 Clear stored data
 Confirm details with naked eyes
 Take out cap from external cap storage part and perform plugging
 3. Normal control
 4. Photographing button?
 Standby vial to be returned?
 Third transfer robot/fourth transfer robot empty?
 Interrupt processing
 Transfer by third transfer robot/fourth transfer robot
 Moved to photographing position?
 Photographing completed?
 Transfer by third transfer robot
 Transfer by fourth transfer robot
 Vial taken out?

FIG.43 0.0 Main menu

| | |
|--------|---|
| FIG.44 | 1.0 Automatic dispensing screen |
| FIG.45 | 1.1 In-process prescription list screen |
| FIG.46 | 1.1.1 Vial take-out error confirmation screen |
| FIG.47 | 1.1.1.1 Vial interior photo display device |
| FIG.48 | 1.2 Drug filling cassette specification screen |
| FIG.49 | 1.2.1a New drug registration screen |
| FIG.50 | 1.2.1a Drug list display screen |
| FIG.51 | 1.2.1a.1.1 NDC master drug delete screen |
| FIG.52 | 1.2.1b NDC code check screen |
| FIG.53 | 1.2.1b.1 Tablet filling screen |
| FIG.54 | 1.2.1b.1.1 Filling confirmation screen |
| FIG.55 | 1.2.2 Cassette list screen |
| FIG.56 | 1.2.3 Cassette-by-cassette tablet inventory list screen |
| FIG.57 | 1.2.3.1 Tablet inventory change screen |
| FIG.58 | 1.3 Processed prescription list screen |
| FIG.59 | 1.4 Filling history drug selection screen |
| FIG.60 | 1.4.1 Filling history display screen |
| FIG.61 | 1.5 Dispensing machine not-yet-transmitted prescription list screen |
| FIG.62 | 1.6 Dispensed vial photo list screen |
| FIG.63 | 1.6.1 Photo display screen |
| FIG.64 | 1.7 Manual dispensing cassette designation screen |
| FIG.65 | 1.7.1 Manual dispensed tablet quantity designation screen |
| FIG.66 | 1.7.2 Cassette list screen |
| FIG.67 | 2.0 Drug table list screen |

| | |
|--------|--|
| FIG.68 | 2.1 Deleted drug confirmation screen |
| FIG.69 | 3.0 Tablet cassette control screen |
| FIG.70 | 4.0 Host disconnection screen |
| FIG.71 | 5.0 Date update time setting screen |
| FIG.72 | 5.1 Program version information display screen |